

Quickstart Guide

HYPOP LIGHTING KIT



Step 1:

Set up a tripod to required height.



Step 2:

Open a softbox and mount onto the tripod.



Step 3:

Screw in a lightbulb into softbox fixture. For safety, make sure there is no power being supplied to the unit at this stage and the power switch is set to the **OFF** position.



Step 4:

Attach the diffusion sheet via the velcro attachments on the edge of the softbox.



Step 5:

Supply power to the light and turn the power switch to the ON position.



Step 6:

Adjust the angle of the softboxes as required.



Step 7:

Repeat for other lights you wish to use.

For more help, contact:
lih-sst@mq.edu.au



MACQUARIE
University
SYDNEY · AUSTRALIA